IoTCoreDeviceDatabaseMaintenance

This view helps for devices maintenance it shows all local and remote devices synchronized, none synchronize or orphan.

From this view we can initialize none synced devices or clean the orphan ones.

DisplayName	Id	Sync Status	Station Ord
device4	device4_d0S2qcnKubgxYGu9wDavT	SYNCHRONIZED	local:|station:|h:18c87
device1	device1_I0S2qcnN3XEgdfu9rjAPf	SYNCHRONIZED	local:|station:|h:18c92
device2	device2_S0S2qcnP7KnzsZu2O6Ncs	SYNCHRONIZED	local:|station:|h:18c9d
device3	device3_s0S2qcnQFiGDdLMuKuzhp	SYNCHRONIZED	local:|station:|h:18ca8
device	device_i0S2qcnj6cMucO0fUg2Xy	SYNCHRONIZED	local:|station:|h:18cb3
device5	device5_P0S2qeYY5ptcJ6QoWMEcg	SYNCHRONIZED	local:|station:|h:18cbf
device6	device6_l0S2qeYaGi6ithH8GttPd	SYNCHRONIZED	local:|station:|h:18cca
device7	device7_R0S2qeYbhLTmpj04zadu7	SYNCHRONIZED	local:|station:|h:18cd5
device8	device8_d0S2qeYctqk0HLO5mJW4z	SYNCHRONIZED	local:|station:|h:18ce0
device9	device9_p0S2qeYdoZis35htSsaWZ	SYNCHRONIZED	local:|station:|h:18ceb
device10	device10_I0S2qeYf7CBoNxdST2IhG	SYNCHRONIZED	local:|station:|h:18cf6
device11	device11_j0S2qeYgEJTMtte80KvgL	SYNCHRONIZED	local:|station:|h:18d01
device12	device12_X0S2qeYi1mBDgCWxmriTt	SYNCHRONIZED	local:|station:|h:18d0c
device13	device13_W0S2qeYjURXo267p6xFll	SYNCHRONIZED	local:|station:|h:18d17
device14	device14_D0S2qeYkEnLvHhSeSHMA0	SYNCHRONIZED	local:|station:|h:18d22
null	CompteurElec2_h0S5Y3c0TAmjTCsRziXR4	REMOTE_ORPHANED	null
null	salle_222_a_227_m0S7YEdv2dMhzFAVJNZZK	REMOTE_ORPHANED	null
null	cafetaria_N0S7YEdvSks3sSEahbIyx	REMOTE_ORPHANED	null
null	plonge_batterie_r0S7YEdsFKGbw0s6YOHSU	REMOTE_ORPHANED	null
null	salle_008_G0S7YEduaVDVdpZnYyYpj	REMOTE_ORPHANED	null
null	Folder_n0S7vxHjU238a6X5RE0lu	REMOTE_ORPHANED	null
null	foyer_n0S7YEdr74pnzbHUI8QR2	REMOTE_ORPHANED	null
null	exterieur_f0S7YEdsNl4xefZf3XWqJ	REMOTE_ORPHANED	null
null	Test_b0S7RVhf25Qyu0XKRGOFQ	REMOTE_ORPHANED	null
null	circulation_r0S7YEdtTn3kn5Hv8VcUu	REMOTE_ORPHANED	null
null	ValueContainer_U0S7RoGBpHK9WIF0NcBe7	REMOTE_ORPHANED	null
null	salle_des_fetes_n0S7YEdssIjL8jvEmLGRT	REMOTE_ORPHANED	null
null	circulation_K0S7YEdvIg4JIiyy9ZRxP	REMOTE_ORPHANED	null
null	salle_020_S0S7YEdvQJAoHISBOYOVJ	REMOTE_ORPHANED	null
null	salle_133_P0S7YEdyz7gXCM1PIsqs1	REMOTE_ORPHANED	null
null	reprographie_salle_007_et_007bis_I0S7YEduWekqKbwZJJ7XD	REMOTE_ORPHANED	null
null	salle_105_O0S7YEdtLKQmtvGjxzWNX	REMOTE_ORPHANED	null
null	salle_016_I0S7YEdsXSeiQy404K1EU	REMOTE_ORPHANED	null
null	autres_locaux_u0S7YEdsD0oykezdtPMFb	REMOTE_ORPHANED	null
null	salle_019_Q0S7YEdsJoYNQmFt4DUHo	REMOTE_ORPHANED	null

Discover   **Clean**   **Initialize**

Columns:

Display Name: The display name of the object in station.

Id: The object id used by the connector (see the sformat for this id in **BtibService ExternalConnector RealtimeConnector [AX Property Sheet]**).

Sync Status: The synchronization status for the object.

- **SYNCHRONIZED**: The object exists in the station and has been created successfully in the remote service.
- **LOCAL_ORPHANED**: The object exists in the station but has not been created in the remote service.
- **REMOTE_ORPHANED**: The object doesn't exists in station but exists in the remote service.

Station Ord: The ord of the object in the station.

Actions:

Discover: Discover objects in the station and there statuses.

Strategy

Local Only

All
Local Only
Remote Only

- **All**: Discover all objects.
- **Local Only**: Discover local orphan only.
- **Remote Only**: Discover remote orphan only.

Clean: Clean the object from the remote service, enabled if the object is remote orphan.

Initialize: initialize the object, enabled only if the object is local orphan.