
## **Communication mode**

The real-time connector is able to connect in full duplexed mode. It can send data and receive commands for points, schedules, alarms and histories.



Outbound Data

Inbound Data