Pulse 4 Decoder

Summary

Pulse 4 sensors decoder

Usage

1. Set up a RestQuery that recovers the Pulse 4 payload to decode
2. Inside the RestQuery's Points, drag and drop a StringPoint from the palette
3. Inside the Value Conversion slot of the point's Proxy Ext, Drag and Drop the V64ToJson component

You should see the result of the conversion in your StringPoint's Out slot