

# btibGoogleIoTCore

**Google Cloud IoT Core** is a fully managed service that allows you to easily and securely connect, manage, and ingest data from millions of globally dispersed devices. Cloud IoT Core, in combination with other services on Cloud IoT platform, provides a complete solution for collecting, processing, analyzing, and visualizing IoT data in real time to support improved operational efficiency.

[Google IoTCore connector specifics](#)

## Get started

---

- [Realtime Connectors](#)
- [Step 1 Set up IoT Core on Google Cloud Platform](#)
- [Step 2 Set up IoT Core connector for devices, points and references](#)
- [Step 3 Send messages to IoT Core from Niagara](#)
- [Step 4 Send alarms to Google IoT Core](#)
- [Step 5 Send commands from google cloud to Niagara](#)
- [Step 6 Consume Data from IoT Core to Google BigQuery](#)
- [Personalize Messages Payload](#)

## Palette documentation

---

- [GoogleIoTCoreConnector](#)
- [GoogleIoTCoreDeviceExt](#)
- [GoogleIoTCorePointExt](#)
- [GoogleIoTCoreAlarmRecipient](#)
- [GoogleIoTCorePointExt](#)
- [GoogleIoTCoreReferenceExt](#)